

Note:

There is a kernel module "touchkitusb" bundle with the kernel 2.6.x.

Unfortunately, It does not provide the calibration utility for touchscreen use.

By OS default, this kernel module will be loaded automatically.

Please be sure to unload this kernel module "touchkitusb" manually before you install the touch screen USB touchkit driver.

You can unload that unwanted USB kernel module via command line.

Ex.

```
rmmod touchkitusb
```